CTOUCH[®] The power to engage

HOW TO CHANGE YOUR FAVORITE APPS

1. Touch the icon you want to change and hold it for 4 seconds.

2. The list with installed apps will pop-up.

3. Select the app you want to


set as your favorite app.



16:12

4. The icon has been changed to your favourite app.





Laser