




CTOUCH Wallom WL Installation manual




CTOUCH
Smart innovation!




Parts:



Mounting kit:




Optional accessories:



PC tray

Fits most mini PCs or other small format players



Monitor support

Used when the constructive wall is not stable enough

Parts:

- A - Power supply
- B - Interface
- C - Floorstand
- D - Frontplate
- E - Wallmounting
- F - Electric lift
- G - Remote
- H - Powercable EU / UK


Mounting kit:

- 2x M8x16
- 2x M8x65
- 4x M6x8
- 10x M8 ring
- 4 x M6 ring
- 8x M8x70
- 1x Cable holder
- 2x End caps
- 2x Adjustable feet


Changes or modifications void any warranty and exclude any liability.
This user manual includes detailed instructions for your product.
Figures and illustrations in this user manual are provided for reference only and may differ from actual equipment appearance. Equipment design and specifications may be changed without notice.

1


Start by putting the adjustable feet and end caps on the floorplate (C). Then fix the floorplate (C) to the bottom of the lift (F).

**2**


Connect the interface (B) on the top of the lift (F). Test the lift by connecting the power supply (A) and put the lift in the maximum position.

**3**


Drill a minimum of four holes in the constructive wall and secure the wallmount (E) using mounting material.

**4**

Place the lift (F) in the Wallmounting (E) and lock with the frontcover (D). Fasten screws after locking.

**5**

Place Cable Holder on the back of the interface (B) and install all cables.

**6**

Place the top two screws in back of the monitor. (monitor supplied separately) Then place the monitor on the interface (B) and fix the top screws. Fasten the lower screws and the lift is ready to use.

